

*Made in the Florida Keys*  
**MANATEE MAILBOXES**

*Installation Instructions*  
**FOR MANATEE & DOLPHIN MAILBOXES**

Installation of the Dolphin and Manatee Mailbox is the same as any standard ground mount mailbox. The easiest way to install these mailboxes is to make a 2" x 4" pressure treated wood box and fill it with concrete for a base. Each mailbox is custom made so it is best to measure your mailbox when it arrives to your destination. Measure the inside edge of the bottom of the mailbox and then cut your wood to size. You can buy all of these materials at Home Depot one (1) 8' 2"x4" PT piece of wood, eight (8) 3 ½ screws for the corners of the box, one (1) 60 - 80 lb bag of concrete and six (6) 2" Stainless screws with square or star head screws so it cannot be unscrewed with a common screw-driver. Once the concrete is dry you place the mailbox on top of the wood frame so the wood fits inside the bottom then screw the mailbox into the wood around the bottom using stainless screws.

You can also use the PVC pipe that is fiber glassed inside the mail boxes. You need a PVC pipe the same size and a coupler to join the two together. You dig a hole cement the PVC in the ground and then join the two pipes together with PVC glue available at any hardware store.

If you have any questions please feel free to contact us!



**305-393-6791**

147 Mohawk St  
Tavernier, FL 33070

[info@manateemailboxes.com](mailto:info@manateemailboxes.com)

[WWW.MANATEEMAILBOXES.COM](http://WWW.MANATEEMAILBOXES.COM)

